

LPR Camera Adjustment Tutorial - Survision


1. LPR Camera Adjustment

LPR Camera Adjustment **tutorial**

1 Vehicle Alignment


First, position the vehicle according to one of two parking scenarios :

A
On-Street
(Angled/parallel parking)



Drive in the lane closer to vehicles

B
Off-Street
(Perpendicular parking)



Drive centered between lanes

Next →

2. Camera Aiming




Camera Aiming

Once you have aligned the vehicle, position the LPR Camera accordingly :

A


On-Street

(Angled/parallel parking)

**B**

Off-Street

(Perpendicular parking)



Previous

Next



3. Framing



Framing

Once you have aligned the vehicle and the camera, go to your PlatEnforce App and using the live view, make sure :

