

PL8RDR Signal Strength

Signal Strength

The PL8RDR is a proxy/bridge to the internet through WIFI or your cellular provider (LTE). When connected, can you open a browser window to see if you are able to browse the internet.

If not, you should check your signal strength.

- If you are a WIFI user you can test signal strength with multiple applications that are typical a free download.
- If you are a LTE user you can see the signal strength by looking at the device's status from the LPR Scanning screen.

By tapping on Status at the top right of the screen you will be presented with a list of items and their connection status.

Signal Strength will appear at the bottom of this list.

The closer to zero the better.

dB m	Co m me nt
-51	Bes t

dB m	Co m me nt
-80	Min im um for bes t con nec tivi ty
-90	Noi sy con nec tio n; not sta ble
-96	<i>our offi ce win do w (us abl e)</i>

dB m	Co m me nt
-10 7	<i>LTE tab let out sid e (us abl e) Ph on e in bas em ent</i>
- 11 1	Wo rst
fail ed	fail ure to get sig nal

Take Command of Your Parking and Security - <https://OperationsCommander.com>

Revision #2

Created 24 May 2024 14:13:27

Updated 21 May 2025 10:30:22